AUGUSt® User Manual

--- EP615

- **EN** Bluetooth Stereo Headset
- FR Ecouteurs Stéréo Bluetooth
- **DE** Bluetooth Stereo Kopfhörer
- Cuffie Stereo Bluetooth
- Auriculares Bluetooth Estéreo

August International Ltd United Kingdom Telephone: +44 (0) 845 250 0586 www.augustint.com

Thank you for purchasing the August EP615 Bluetooth Stereo Headset. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble the EP615, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country.

Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

1. Safety Instructions

■ Storage and Use



Keep this device away extreme temperatures.



Keen the device away environment



Never expose the device to moisture. dust oil or smoke.



dropping or exposing to impacts.



this device as part of your luggage please ensure it is securely stored impact damag



Never strike or scratch this device with any sharp object.

Maintenance

Please unplug all leads before cleaning this device.



device and buttons with a soft cloth.



device with an abrasive cloth orapply detergent. alcohol or cleaning products

2. Main Features

Wireless Headphones for Bluetooth Devices Micro USB charging port Integrated Microphone for Hands Free Calls Built-in Rechargeable Battery Range: up to 10m (Class II)

Bluetooth Version: Bluetooth V4.0


3. Accessories





- 1) USB charging cable
- 2) User manual

4. Part Names and Functions



-2-

- 1) Volume Up/Previous Track
- 2) Volume Down/Next Track 3) Status LED
 - 4) Power / Play/ Pause/ Answer
 - 5) Microphone
 - 6) Power Socket
- 7) NFC

5. Operation

5 1 Switch On / Off

To switch on the device, press and hold the button for 2 seconds.

To switch off the device, press and hold the button for 3 seconds. The status LED will flash red then turn off

5.2 Bluetooth Connections

Turn the device on, The EP615 will automatically reconnect to the last paired Bluetooth device if it is in range.

To connect to a new device, first ensure the EP615 is switched off, then press and hold the

- ▶ button until the LED flashes red and blue
- (approx. 4 seconds). To connect to a new device. please disconnect the current Bluetooth connection to the EP615 on your device.

- For mobile phones

- 1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed)
- 2) Select "EP615" from the available devices and confirm connection.
- 3) The status LED flashes blue to indicate a successful connection.

Note:

Accessing Bluetooth settings on mobile phones varies for each phone, to find the information for your phone, please refer to its user manual.

- For computers

1) Enable the Bluetooth function on your computer.
2) Select "Devices and Printers" from the Control

2) Select "Devices and Printers" from the Control Panel and click "Add a Device".

 Select "EP615" from the available devices, the system will install the driver automatically.

Note: For Windows XP and Vista, a third-party Bluetooth driver is needed (not included).

- The status LED flashes blue to indicate a successful connection.
- 5) If the EP615 is not automatically set as your output device, select "Sound" from the control panel then highlight the EP615 and select "Set Default".

Note: When switched on, the EP615 will automatically reconnect to the last paired Bluetooth device if it is in range.

- NEC

- Enable Bluetooth and NFC on your source device.
- Touch the NFC area of your source device against the NFC area on the left side of the EP615. They will automatically pair with each other
- 3) Confirm Bluetooth pairing if prompted. "EP615" will now be listed in your source device's Bluetooth device list.
- 4) To disconnect your device, touch the NFC area of your device against the NFC area on the left side of the EP615

Note: The first time you pair the EP615 through

NFC, you will need to tap twice. Once to turn the headphones on and once to pair.

5.3 Remote Control

The EP615 is able to control the music playing on either a mobile phone or a computer with a Bluetooth connection.

Press "►" to pause or resume playing music.

Press and hold "V+" or "V-" to increase or
decrease the volume

Press "V+" or "V-" to select the previous or next track.

Note: Music playing control is only compatible with devices that support A2DP, please refer to your devices user manual for its A2DP compatibility.

5.4 Hands-free Calling

Whilst connected to your mobile phone, the EP615 will act as a hands-free system for calls.

Press **T** to pick up or hang up a call. Press and hold **T** for 2 seconds to reject the incoming call. Press **T** twice to dial last dialled number.

During a call, you can mute your caller. Press and hold \Re for until a beep sounds to enter mute mode; press and hold \Re again, after the beep the call is un-muted.

6. Charging

When the power is low, the LED flashes red. To charge the EP615, connect the micro USB lead to the device's power socket, and the other end of the USB cable to a powered USB port.

The status LED lights red whilst charging and lights blue once the battery is fully charged.

Note:

- 1) Only use USB power plugs that have been properly certified.
- 2) Make sure that the headphone is fully charged for at least 6 hours for before first use.
- The headphones must be fully charged before use if they have been unused for longer than 1 year.

7. Specification

Bluetooth Specification	Bluetooth V4.0 + NFC
Operating Range	Up to 10m
Frequency Response	20Hz - 20KHz
Speaker Output	10mW
SNR	93.2db±3dB
Distortion	≤0.3%
Battery	3.7V/130mah Built-in Li Polyme Battery
Working Time	8 Hours
Charging Time	3 Hours
Standby Time	135 Hours
Weight	43g
Dimensions	48 x 58mm, Neck Band Length: 335mm

8. Troubleshooting

Problem	Solution
Won't turn on	Please charge the EP615.
Can't find the EP615	Confirm EP615 is in pairing status and within 10 meters from the device.
Can't install the driver for EP615	Update the driver of the Bluetooth module on your computer.
The sound quality is intermittent in Bluetooth mode	Disable the Wi-Fi on your source device.
No sound	Check the volume on both source device and EP615.
Can't connect to Bluetooth on Windows XP or Vista	Third party software may be required, please contact the manufacturer of your Bluetooth chip for more information.
Can't connect to Bluetooth in Windows 7+	Download all updates for Windows and your Bluetooth driver, these may need to be manually downloaded from the Bluetooth chips manufacturers website.

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

The warranty is only valid within the country where the product is purchased.

The product must be correctly installed and operated in accordance to the instructions given in this user manual.

The product must be used solely for domestic purposes.

The warranty only covers the main unit, and does not cover the accessories

The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.

The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages. Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.

Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586 Email: service@augustint.com