

AUGUST®

User Manual

MS515



August International Ltd
United Kingdom
Tel: +44 (0)845 250 0586
www.augustint.com

- EN Bluetooth® Stereo Speakers
- FR Enceintes Stéréo Sans-fil Bluetooth®
- DE Bluetooth® Stereo Lautsprecher
- IT Altoparlanti Stereo Bluetooth®
- ES Altavoces Bluetooth® Estéreo

User Manual

Thank you for purchasing the August MS515 Bluetooth Stereo Speakers. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble this product, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

Quick Start Guide MS515

Main (Left)



Secondary (Right)



1. Power Socket
2. Connecting Socket
3. Audio In
4. Multifunction Switch
5. Power Switch

Please fully charge both speakers before first use. To charge, use the power cable to connect both speakers to a powered USB port. Whilst charging, the LED lights red and turns off once fully charged.

1. Use the connecting cable to connect the main and secondary speaker.



2. Switch Main speaker on

Note: The main speaker will automatically enter pairing mode, indicated by the LED strobing alternately red and blue, if the last used source device is not available. If the MS515 does not enter pairing mode automatically, press and hold the multifunction switch until a two tone notification sounds.

3. Pair your source device with “MS515”

Note: If you are unfamiliar with the Bluetooth feature of your source device, please refer to its user manual for detailed instructions.







4. Once successfully paired and connected, the blue LED starts to flash once per 2 seconds.

Contents

1. Safety Instructions.....	4
2. Main Features.....	5
3. Accessories.....	5
4. Part Names and Functions.....	5
5. Operation.....	6
5.1 Switch Speakers On/Off.....	6
5.2 Bluetooth Connection.....	6
5.3 Volume and Track Control.....	7
5.4 Audio-In.....	8
6. Charging.....	9
7. Specification.....	9
8. Troubleshooting.....	10
9. Warranty.....	11

1. Safety Instructions

■ Storage and Use

	Do not store or use this device in extreme temperatures.		Do not store or use this device in wet or damp environments.
	Do not expose this device to dust, oil or smoke.		Do not drop or strike this device.
	When transporting this device store securely to avoid impact damage.		Do not scratch this device with sharp objects.

■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
---	--	--	--

2. Main Features

- Wireless Audio from any Bluetooth Device
- Speakers for Stereo Sound on Your Home TV
- Audio-In Socket for Non Bluetooth Devices
- Long Life Built-in Rechargeable Batteries

3. Accessories



Power Cable



1.2m Red Band L-R Speaker Cable
3m Red Band L-R Speaker Cable
3.5mm Audio Cable



User Manual

4. Part Names and Functions

Main (Left)



1. Power Socket
2. Connecting Socket
3. Audio-In Socket
4. Multifunction Switch
5. Power Switch

Secondary (Right)



2

5. Operations

5.1 Switch Speakers On/Off

The power switch for the main speaker is as slider switch located on the rear of its unit.

5.2 Bluetooth Connection

5.2.1 Connection to the Main Speaker

Connect the main and secondary speaker with the connecting cable, then switch the main speaker on.

Press and hold the multifunction switch on the main speaker until a two tone notification sounds to indicate pairing mode. Pairing mode is indicated by the LED on the main speaker strobing alternately red and blue.

Note: The main speaker switches off automatically after 10 minutes if not paired, switch off and on to switch back on.

■ For mobile phones

- 1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed).
- 2) Select "MS515" from the available devices.
- 3) Once successfully paired and connected, the blue LED starts to flash once per 2 seconds.

■ For computers

- 1) Enable the Bluetooth function on your computer.
- 2) Select "Devices and Printers" from the Control Panel and click "Add a Device".
- 3) Select "MS515" from the available devices, the system will install the driver automatically.
- 4) Once successfully paired and connected, the blue LED starts to flash once per 2 seconds.

■ For a TV or Set-Top Box with Integrated Bluetooth

Connection

- 1) Scan for available Bluetooth devices on your TV or Set-Top Box (see your TV or Set-Top Box user manual for instructions if needed).
- 2) Select “MS515” from available devices.
- 3) Once successfully paired and connected, the blue LED starts to flash once per 2 second.

■ For TV with No Bluetooth Connection

To connect to a TV or Set-Top box without a Bluetooth connection, you will require a Bluetooth Transmitter such as the August MR250.

- 1) Plug the transmitter into the headphone socket of your TV.
- 2) Switch the transmitter on and enter pairing mode (for more information, please refer to the transmitter user manual). Please ensure that no other Bluetooth device is available for pairing nearby.
- 3) The transmitter will automatically pair with the MS515. Once successfully paired and connected, the blue LED starts to flash once per 2 seconds.

Note: If no source device is available to pair after entering pairing mode in 10 minutes, the main speaker will turn off automatically. To re-start it, please manually switch it from On to Off and switch On again.

5.3 Volume and Track Control

5.3.1 Volume Control

To adjust the volume either slide and hold the multifunction switch to the left or right or adjust the volume on your source device.

5.3.2 Track Control

To control the track slide the multifunction switch to the left or right to skip or repeat track. Press the multifunction switch to play or pause playback.

Note: Volume and track control require A2DP on your source device, please refer to its user manual to see if it has A2DP.

5.4 Audio-In

To use the MS515 with a non-Bluetooth source device, connect the main and secondary speaker with the connecting cable then turn the main speaker on. Once both are switched on, connect the source device to the mainspeaker audio in socket using the provided 3.5mm audio cable.

6. Charging

To charge the MS515, connect the micro USB lead to the device's power socket, and the other end of the power cable to a powered USB port. The LED lights red whilst charging and turns off once the battery is fully charged.

7. Specification

Bluetooth Specification	Bluetooth v5.0
Bluetooth Profile	A2DP, AVRCP
Operating Range	Up to 10m (Class 2)
Frequency Response	90Hz – 20KHz
Speaker Output	5W x 2
SNR	≥80dB
Distortion	≤1.0% at 1kHz
Battery	3.7V/1600mAh Built-in Lithium Battery
Working Time	Approximately 6 hours
Charging Time	Approximately 3.5 Hours
Standby Time	30 Days
Weight of Each Speaker	260g
Dimensions	106.5 x 74 x 69.4mm

8. Troubleshooting

Problem	Solution
Speakers will not switch on	Please charge the MS515
Source device can not find MS515	Confirm MS515 is in pairing status and within 10 meters from the device
Windows does not install the MS515 driver	Update the driver of the Bluetooth module on your computer
Intermittent sound quality in Bluetooth mode	Disable the Wi-Fi on your source device
No sound	Check the volume on both source device and MS515
Can not connect to Bluetooth on Windows XP or Vista	Third party software may be required, please contact the manufacturer of your Bluetooth chip for more information
Can not connect to Bluetooth on Windows 7+	Download all updates for Windows and your Bluetooth driver, these may need to be manually downloaded from the Bluetooth chips manufacturers website

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main units, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexperienced repairs. The manufacturer disclaims any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The Declaration of conformity may be consulted online at <http://www.augustint.com/en/declaration>.



Industry Canada Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.