August International Ltd United Kingdom Tel: +44 (0) 845 250 0586 www.augustint.com



User Manual EP614



- EN Bluetooth® Sports Headphones
- Écouteurs Bluetooth® pour le Sport
- DE Bluetooth® Sport Kopfhörer
 - Auricolari Bluetooth® per Sports
- Auriculares Bluetooth® Sports

User Manual

Thank you for purchasing the August EP614 Bluetooth Sports Headphones. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble this product, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

Quick Start Guide

Please fully charge the EP614 before first use. To charge, use the Power Cable to connect the EP614 to a powered USB port. Whilst charging, the LED lights red and turns blue once fully charged.

Bluetooth Setup

- 1. Ensure EP614 is powered off.
- 2. Press and hold the Control Button until the LFD flashes alternately red and blue
- 3. Pair your source device to EP614

Note: If you are unfamiliar with the Bluetooth feature of your source device, please refer to its user manual for detailed instructions. If your source device does not have Bluetooth and you would like to connect to it wirelessly, we recommend the August MR250 Bluetooth transmitter.

For PC connections, Windows XP and Windows Vista require third party software to connect to Bluetooth speakers. If you are using a later version of Windows and the EP614 is not outputting audio, please check that the drivers for your PCs Bluetooth module are up to date and that the Audio Output source is set to FP614

Ear Piece Setup

The ear buds slide on to the driver. Choose the most comfortable combination for your ears. Please be aware that sound quality can be greatly affected by ill fitting earbuds, and an airtight fit is essential for bass reproduction.

1. Safety Instructions

■ Storage and Use



Do not store or use this device in extreme temperatures.



Do not store or use this device in wet or damp environments.



Do not expose this device to dust, oil or smoke.



Do not drop or strike this device.



When transporting this device store securely to avoid impact damage



Do not scratch this device with sharp objects.

■ Maintenance

Please unplug all leads before cleaning this device.



Wipe the device and buttons with a soft cloth.

-1-



Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning

2. Main Features

- Wireless Headset for Bluetooth Devices
- Integrated Microphone for Hands-free Calls
- Built-in Rechargeable Battery
- Micro USB Charging Port
- Range: up to 10m(Class II)

3. Accessories








4. Device Layout





- 1. Status LED 2. Control Button
- Control Button
 Charging Socket
- 4. Microphone
- 6. –

5. Operation

5.1 Power

Please fully charge the EP614 before first use or if left unused for a long period of time. To charge, use the power cable to connect the headphones to a powered USB port. Whilst charging, the LED lights red and turns blue once fully charged.

Note: Only use USB charging plugs certified to the relevant local safety standards to charge these headphones.

5.2 Switch On / Off

To switch the EP614 headphones on, press and hold the Control Button until the status LED flashes blue and the power on tone sounds.

To switch the EP614 headphones off, press and hold the Control Button until the status LED lights red and the power off tone sounds.

5.3 Bluetooth Setup

The EP614 connects to Bluetooth enabled source devices to playback audio. It will automatically connect to the last connected device when switched on, to pair to a new device:

- 1. Ensure EP614 is powered off.
- 2. Press and hold the Control Button until the LED flashes alternately red and blue.
- 3. Pair your source device to EP614.

To pair to a second source device.

- Press and hold the Control Button until the LED flashes alternately red and blue.
- 5. Pair your second source device to EP614.
- 6. Switch the EP614 off and on.

Note: If you are unfamiliar with the Bluetooth feature of your source device, please refer to its user manual for detailed instructions. If your source device does not have Bluetooth and you would like to connect to it wirelessly, we recommend the August MR250 Bluetooth transmitter. For PC connections, Windows XP and Windows Vista require third party software to connect to Bluetooth speakers. If you are using a later version of Windows and the EP614 is not outputting audio, please check that the drivers for your PCs Bluetooth module are up to date and that the Audio Output source is set to EP614

Ear Piece Setup

The ear buds slide on to the driver. Choose the most comfortable combination for your ears. Please be aware that sound quality can be greatly affected by ill fitting earbuds, and an airtight fit is essential for bass reproduction.

5.4 Remote Control

Short press the Control Button to play and pause music.

Short press the + or - button to select the next or previous track.

Long press the + or - button to adjust the volume.

Note: The remote control is only compatible with devices that support A2DP, please refer to your devices user manual for its A2DP compatibility.

5.5 Hands-free Calling

Whilst connected to your mobile phone, the EP614 will act as a hands-free system for calls.

Press the Control Button to pick up or hang up a phone call.

Press and hold the Control Button to reject an incoming call.

Double tap the Control Button to redial the last called number.

6. Specifications

Bluetooth Specification	v4.1 + EDR
Operating Range	Up to 10m
Frequency Response	20Hz-20KHz
Speaker Output	2 x 9.5mW
SNR	94dB
Distortion	≤3% at 1KHz
Battery	3.7V/60mAh Built-in Li-Polymer Battery
Working Time	3.5 hours
Charging Time	1.5 hours
Weight	17g
Dimensions	75x65x13mm

7. Troubleshooting

Problem	Solution
Unable to switch on	Fully charge the EP614. Press and hold the Control Button for two seconds.
Unable to pair source device	Confirm that the EP614 is in pairing mode. Confirm that the EP614 is within 10m of the source device. Delete existing connection to EP614 from source device and repair.
Can't install the driver for EP614 on a computer	For Windows 7 and 8, update the Bluetooth driver from the Bluetooth module manufacturers website. For further information on you PCs Bluetooth module, please consult your PC supplier. Bluetooth headsets are not supported by Windows XP and Vista, a third party Bluetooth driver can be used to solve this issue.
The sound quality is intermittent in Bluetooth mode.	Please ensure the headset is within 10 meters of your source device. Disable the Wi-Fi on your source device.
No sound	Check the volume on both the source device and the EP614. If the headset is connected to a computer, please check that the headset is set as the current audio out device
The mobile phone asks for a PIN code	• The PIN code for the EP614 is 0000

8. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
 The warranty only covers the main unit, and does not cover
- the accessories.

 The warranty does not cover the damage caused by misuse,
- negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586 Email: service@augustint.com This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at August International Ltd, Rawmec Business Park, Plumpton Road, Hoddesdon, EN11 0EE, United Kingdom.

Industry Canada Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates used and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or.

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the
- equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.

For details of further relevant technical standards, please contact us at the address above.